










# HOW TO INSTALL THIS DEADBOLT LOCK

1 MARK DOOR	2 BORE HOLES	3 INSTALL DEADBOLT	4	5 INSTALL STRIKE
 <p>TEMPLATE</p> <ul style="list-style-type: none"> <li>Mark site of lock and bore.</li> </ul>	 <p>BASE HOLE</p> <ul style="list-style-type: none"> <li>Bore the holes through door.</li> <li>Cut out base.</li> </ul>	 <p>DEADBOLT</p> <ul style="list-style-type: none"> <li>Keeping the arrow sign in the deadbolt always upward.</li> </ul>	 <p>Loosen the screws(A) and pull out the knob (if have), loosen the screws of cover(B) and pull out the cover</p>	 <p>STRIKE</p> <p>Line of door thickness</p>
6 INSTALL CYLINDER	7 DOUBLE CYLINDER	8	INSTRUCTION FOR ADJUSTABLE DEADBOLT	
 <p>TORQUE BAR CAM</p> <ul style="list-style-type: none"> <li>Keeping cylinder torque bar horizontally insert in to cam slot.</li> </ul>	 <p>PREPARE DOOR EXACTLY AS IN STEPS 1, 2, 3, 4 AND 6 ABOVE. INSTALL INSIDE CYLINDER keeping cylinder torque bar vertically insert in to cam slot. SAME AS STEP 6 ABOVE.</p>	 <p>Install cover on the lock and tightening screws (B), then put the knob on lock and tightening screws(A)</p>	 <p>Press the end of the deadbolt. Turn the latchcover pull or push make backset become 70mm (2 3/4") or 60mm (2 3/8").</p> <p>60mm (2 3/8") 70mm (2 3/4")</p>	

